Operation Guide 3560

CASIO®

ENGLISH

You can also find information about operational procedures at the CASIO website.

https://s.casio.jp/mw/en/3560/



EN-1

About This Manual



- \bullet Button operations are indicated using the letters shown in the illustration.
- illustration.

 Each section of this manual provides you with the information you need to perform operations in each mode.

 Note that the product illustrations in this manual are intended for reference only, and so the actual product may appear somewhat different than depicted by an illustration.

Contents

About This Manual	
Configuring Time and Date Settings To configure time and date settings	
Selecting a Mode	EN-8
Alarm	EN-10
To set the alarm time	EN-11
To stop the alarm	EN-12
To enable and disable the Daily Alarm and Hourly Time Signal	EN-12
To test the alarm	EN-12
Stopwatch	EN-13
To measure elapsed time	
	EN-3

EN-14 Main Indicators EN-15 Specifications ..

Watch Features

♦Alarm

♦Stopwatch

You can also find information about operational procedures at the CASIO website.



https://s.casio.jp/mw/en/3560/

EN-4

EN-5

Configuring Time and Date Settings

To configure time and date settings



- In the Timekeeping Mode, press © three times. This causes the seconds to flash on the display.
- 2. Press (A) to move the flashing in the sequence shown below to select a setting.



3. Use (ii) to change the selected setting

Screen	This setting item:	
50	Reset the second to 00 • 30 to 59 seconds: Adds 1 to minutes	
°10:58	Change the hour or minute Holding down © changes the current selection at high speed.	
6 30FR	Change the month, day, or day of the week Holding down ① changes the current selection at high speed.	

- 4. Press © to exit the setting screen.
- The watch returns to the Timekeeping Mode automatically if you do not perform any button operation for one or two minutes in the Time Setting Mode.

Selecting a Mode

- Press © to change the mode.
- After you perform an operation in any mode, pressing © returns to the Timekeeping Mode.
- Press (B) in any mode to illuminate the face of



PM indicator Hour : Minutes Seconds

* SU: Sunday MO: Monday TU: Tuesday WE: Wednesday TH: Thursday FR: Friday SA: Saturday

You can also find information about operational procedures at the CASIO website. https://s.casio.jp/mw/

FN-8

FN-9

Operation Guide 3560

Alarm

When the Daily Alarm is turned on, the alarm sounds for 20 seconds at the preset time each day. When the Hourly Time Signal is turned on, the watch beeps every hour on the hour.

nour on the nour.

The watch returns to the Timekeeping Mode automatically if you do not perform any button operation for one or two minutes in the Alarm Mode.

1. In the Alarm Mode, press (A),



- 2. Press (1) to increase the flashing digits.
 - Holding down
 changes the setting at high speed.
 Press
 to return to the Timekeeping Mode.

EN-10 EN-11

To stop the alarm
Press any button to stop the alarm after it starts to sound.

To enable and disable the Daily Alarm and Hourly Time Signal

Press (i) while in the Alarm Mode to change the settings of the Daily Alarm and Hourly Time Signal in the following sequence.



To test the alarm

Hold down

while in the Alarm Mode to sound the alarm.

Stopwatch



The Stopwatch Mode lets you measure elapsed time. The range of the stopwatch is 59 minutes, 59.9 seconds.



Main Indicators



Number	Name	See
1	PM indicator	EN-8
2	Stopwatch Mode	EN-13
3	Alarm on indicator	EN-12
4	Hourly time signal on indicator	EN-12

Specifications

Accuracy: ±30 seconds per month average.

Basic Functions:
Hour, minute, second, month, day, day of the week, a.m./p.m.(P)
Auto-calendar set at 28 days for February

Setting units: Hour, minute Beeper: 20 seconds Hourly time signal: Watch beeps every hour on the hour.

Stopwatch:
Measuring units: 1/10 second
Measuring capacity: 59 minutes, 59.9 seconds (60 minutes)

Other: LED light

EN-14

Battery:
CR1616 x 1
Battery life: Approximately 3 years
Conditions:

- Alarm: Once (20 seconds)/dayIllumination: Once (1.5 seconds)/day

Specifications are subject to change without notice.

EN-15